

### **Loading TRITON.PCG onto your Krome:**

1. After downloading the .zip file from our website, it will need to be unzipped.
2. After unzipping the download, you will see a file in the newly created folder named TRITON.PCG. Copy the TRITON.PCG file onto your SD (max. 2 GB) or SDHC card (max. 32 GB).
  - *Note: SDXC cards are not supported.*
3. Put the card into your Krome, and press the MEDIA button.
4. If you are not already on the “Load” tab, touch “Load” on the bottom of the screen.
5. Touch “TRITON.PCG” to highlight it, and then touch the “Load” button.
6. Verify that “Load TRITON.SNG too?” is not selected, and then touch “OK”.
7. The screen will briefly display, “Now writing into internal memory.” When this message disappears, loading has completed.

To access these sounds, press the PROG button, then press the BANK F button. The first sound you will see is “A000 Super Grand”. Note that these sounds will be retained even if you turn off your Krome’s power, so you do not need to repeat this process every time you turn on your Krome.